


# REPLACEMENT PARTS - MODEL TB635 EC

## 4-CYCLE GAS TRIMMER

PPN 41ADZ63C766







Item	Part No.	Description	Item	Part No.	Description
1	753-08320	Top Housing Assembly	17	791-182569	Thrust Washer
2	753-08319	Air Purge Primer	18	9162-1	Clutch Washer
3	721-04466	O-Ring	19	2557	Power Shaft Spacer
4	731-10184A	Intake Port	20	753-05533	Thrust Washer
5	791-181003	Screw	21	753-06246	Flywheel Assembly (includes 22)
6	753-08053	Boot Assembly	22	714-04016	Key
7	710-06238	Screw	23	753-08482	Module Assembly
8	753-08304	Air Cleaner Assembly	24	710-06224	Screw
9	753-06470	Screw	25	753-08322	Clutch Cover Assembly (includes 26)
10	753-08323	Carburetor Assembly (includes 11)	26	710-06284	Screw
11	791-181751	O-Ring	27	1755	Screw
12	710-06003	Screw	28	731-08903-1	Muffler Housing
13	753-08325	Fuel Tank Assembly	29	753-08324	Muffler Assembly (includes 30)
14	753-05259	Fuel Tank Pad	30	753-05246	Screw
15	753-06167	Lead Wire	31	750-04914	Air Cleaner Spacer
16	753-08114	Clutch Assembly (includes 17 & 18)	32	721-04508	Muffler Gasket

# REPLACEMENT PARTS - MODEL TB635 EC

## 4-CYCLE GAS TRIMMER

PPN 41ADZ63C766



Item	Part No.	Description
1	753-08326	Shortblock Assembly
2	731-08920A-9	Oil Fill Plug
3	721-04509	O-Ring
4	753-08204	Oil Fill Tube
5	9054	Screw
6	794-00082	Spark Plug
7	753-08321	Starter Housing Assembly (includes 8)
8	710-04194	Screw

Item	Part No.	Description
1	753-08670	Shortblock Assembly
2	731-08920A-9	Oil Fill Plug
3	721-04509	O-Ring
4	753-08204	Oil Fill Tube
5	9054	Screw
6	794-00082	Spark Plug
7	753-08667	Starter Housing Assembly (includes 8)
8	710-04194	Screw

# REPLACEMENT PARTS - MODEL TB635 EC

## 4-CYCLE GAS TRIMMER

PPN 41ADZ63C766

Item	Part No.	Description
1	753-08344	Throttle Housing Assembly (includes 2 - 5)
2	731-08433C-10	Throttle Trigger Lock-Out
3	791-182405	Throttle Switch Assembly
4	753-05517	Throttle Trigger
5	753-05007	Throttle Trigger Spring
6	731-08926	Hanger
7	753-08328	Upper Drive Shaft Assembly
8	746-05123	Throttle Cable Assembly
9	753-06039	D-Handle Assembly (includes 10)
10	753-06040	Bolt
11	753-1190	Split Boom Coupler (includes 12)
12	791-182057	Coupler Anti-Rotation Screw
13	753-08327	Lower Drive Shaft Housing
14	753-04282	Shield Mount Hardware
15	753-04283	Shield Assembly (includes 16)
16	791-180553	Blade Assembly
17	753-08156	Cutting Head Assembly (includes 18)
18	731-10783-1	Bump Knob

