



WARNING! When the FLEX™ Pressure Washer attachment is attached to the FLEX™ Power Base, the engine must **only** be started after the water supply is connected and turned on with water flowing through the pressure washer. **Failure to have the water source connected with water flowing through the pressure washer prior to starting the engine of the FLEX™ Power Base will cause irreparable damage to the pressure washer pump.**

REMEMBER: Always turn the water source on **full** before attempting to start the engine!

TROY-BILT LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019



ADVERTENCIA! Cuando el archivo adjunto Lavadora de Presión FLEX™ se une a la base de potencia FLEX™, el motor sólo se debe iniciar después de que el suministro de agua está conectada y encendida con el agua que fluye a través de la lavadora a presión. Si no se tiene la fuente de agua conectada con el agua que fluye a través de él de lavado a presión antes de arrancar el motor de la base de potencia FLEX™ causará un daño irreparable a la bomba de agua a presión.

RECUERDE: desconecte siempre la fuente de agua en su totalidad antes de intentar arrancar el motor!

TROY-BILT LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
