


REPLACEMENT PARTS - MODEL TB225

2-CYCLE CULTIVATOR

PPN 21BK225G766




Item	Part No.	Description
1	753-06833	Rear Housing (includes 1, 2 & 19)
2	791-181862	Screw
3	791-181345	Screw
4	753-06792	Muffler
5	753-06847	Spark Plug
6	791-182723	Screw
7	753-06184	O-Ring
8	753-06189	Insulator Assembly (includes 8 & 10)
9	753-06185	O-Ring
10	753-06288	Carburetor
11	753-06253	Gasket
12	753-06916	Air Cleaner Base
13	753-05253	Screw
14	753-06835	Plate
15	753-06836	Filter
16	753-06837	Air Cleaner Cover
17	753-08008	Screw
18	753-06174	O-Ring
19	753-06839	Lead Wire

Item	Part No.	Description
20	753-06275	O-Ring
21	753-06841	Shortblock (includes 6, 7, 21 & 23)
22	753-06840	Module
23	753-06175	Flywheel
24	753-06247	Washer
25	753-06842	Starter Housing
26	791-181862	Screw
27	753-06218	Spacer
28	753-05860	Clutch Assembly
29	753-06843	Clutch Cover
30	1757	Nut
31	753-06844	Bolt
32	9689A	Screw
33	791-181345	Screw
34	753-06845	Spacer, Rubber
35	753-06846	Fuel Tank (includes 37 & 38)
36	9206A	Fuel Tank Screw
37	791-182612	Fuel Tank Cap
38	791-182405	Switch

REPLACEMENT PARTS - MODEL TB225

2-CYCLE CULTIVATOR

PPN 21BK225G766



Item	Part No.	Description
1	753-04044	Foam Grip
2	753-05940	Spring
3	753-06808	Throttle
4	753-06319	Handle
5	753-06831	Throttle Cable
6	753-06832	Cap
7	10591	Eyelet Bolt
8	753-05527	Nut
9	791-182899	Bolt
10	753-04052	Washer
11	791-182677	Knob
12	753-06809	Handle
13	753-06813	Upper Bracket
14	753-04060	Screw
15	710-1026	Bolt
16	753-04052	Washer
17	753-04061	Nut
18	753-06814	Lower Bracket
19	753-04061	Nut
20	753-06817	Square Tube
21	714-04106	Clevis Pin
22	753-04057	Cotter Pin
23	753-04062	Cap
24	753-04437	Wheel (includes 23)
25	791-182910	Washer
26	753-06815	Spacer
27	753-06816	Axle
28	753-05985	Clip
29	753-05987	Tine (Left Inner, Right Outer)
30	753-05986	Tine (Left Outer, Right Inner)
31	791-182195	Screw
32	753-06063	Gearbox (includes 31)
33	710-0599	Screw
34	753-04499	Flex Shaft
35	753-06812	Tube (includes 34)
36	753-06810	Shield