


# REPLACEMENT PARTS - MODEL TB272V

## 2-CYCLE BLOWER / VACUUM

PPN 41AR272V766




| Item | Part No.  | Description                           | Item | Part No.   | Description                           |
|------|-----------|---------------------------------------|------|------------|---------------------------------------|
| 1    | 753-06027 | Muffler Assembly (includes 2 & 3)     | 12   | 753-05949  | Lead Wire                             |
| 2    | 753-06294 | Muffler Screws                        | 13   | 753-06690  | Throttle Cable                        |
| 3    | 753-05946 | Muffler Gasket                        | 14   | 753-06189  | Insulator Assembly (includes 15)      |
| 4    | 753-06687 | Shortblock Assembly (includes 5 - 11) | 15   | 753-06185  | Insulator O-Ring                      |
| 5    | 710-04715 | Screw                                 | 16   | 753-08637  | Carburetor Assembly (includes 17)     |
| 6    | 753-06847 | Spark Plug                            | 17   | 753-06253  | Carburetor Gasket                     |
| 7    | 753-06443 | Module Assembly                       | 18   | 753-08636  | Air Cleaner Assembly (includes 19)    |
| 8    | 753-06827 | Cylinder Gasket                       | 19   | 791-181757 | Air Filter                            |
| 9    | 753-06175 | Flywheel Assembly                     | 20   | 753-06720  | Fuel Tank Assembly (includes 21 & 22) |
| 10   | 736-04107 | Washer                                | 21   | 710-04194  | Screw                                 |
| 11   | 712-04137 | Nut                                   | 22   | 753-06857  | Fuel Cap                              |

# REPLACEMENT PARTS - MODEL TB272V

## 2-CYCLE BLOWER / VACUUM

PPN 41AR272V766



| Item | Part No.   | Description                          | Item | Part No.   | Description                              |
|------|------------|--------------------------------------|------|------------|--|
| 23   | 753-06694  | Muffler Cover Assembly (includes 33) | 37   | 1755       | Screw                                    |
| 24   | 753-05936  | Upper Blower Tube                    | 38   | 753-06696  | Door Lock                                |
| 25   | 753-05937  | Lower Blower Tube                    | 39   | 753-06678  | Intake Cover (includes 37 & 38)          |
| 26   | 753-06660  | Upper Vacuum Tube                    | 40   | 753-05918  | Spring                                   |
| 27   | 791-180467 | Lower Vacuum Tube                    | 41   | 753-06679  | Impeller Housing                         |
| 28   | 753-05932  | Outer Trigger Lock                   | 42   | 912-0237   | Nut                                      |
| 29   | 753-05919  | Handle Grips                         | 43   | 753-05928  | Washer                                   |
| 30   | 791-182405 | Switch                               | 44   | 753-05929  | Impeller                                 |
| 31   | 753-05925  | Wavey Washer                         | 45   | 791-181862 | Screw                                    |
| 32   | 753-05924  | Inner Trigger Lock                   | 46   | 753-06693  | Impeller Housing                         |
| 33   | 710-04194  | Screw                                | 47   | 753-06695  | Engine Cover Assembly (includes 33 & 45) |
| 34   | 753-05930  | Throttle Trigger                     | 48   | 753-06658  | Elbow Tube                               |
| 35   | 753-05926  | Latch Tube                           | 49   | 753-06659  | Bag                                      |
| 36   | 753-05939  | Latch Spring                         |      |            |  |