


REPLACEMENT PARTS - MODEL TB304C EC ELECTRIC START CAPABLE 4-CYCLE TRIMMER

PPN 41AD304C866



Item	Part No.	Description	Item	Part No.	Description
1	753-09884	Engine Cover Assembly (includes 2 & 3)	22	753-06948	Carburetor Gasket
2	710-04194	Cover Screw	23	751-16046-4	Carburetor w/Primer
3	710-04604	Screw	24	791-181751	Air Cleaner O-Ring
4	753-05901	Rocker Cover	25	841-034673S	Air Cleaner Cover Assem. (includes 26)
5	753-05902	Rocker Cover O-Ring	26	753-05254	Air Filter
6	753-05910	Cylinder O-Ring	27	710-04517	Screw
7	753-10205	Breather Hose	28	753-06797	Fuel Tank Assembly (includes 29)
8	753-05408	Oil Plug (includes 9)	29	753-1229	Fuel Cap
9	791-182290	Oil Plug O-Ring	30	753-05259	Fuel Tank Pads
10	841-020721S	Crankcase Cover (includes 11)	31	753-10204	Starter Housing Assem. (includes 3 & 38)
11	753-05238	Crankcase Cover O-ring	32	753-06281	Clutch Assembly
12	753-06221	Flywheel Assembly	33	753-09887	Clutch Cover (includes 2)
13	725-15385	Lead Wires	34	791-182519	Anti-Rotation Screw
14	753-10985	Module Assembly	35	9689A	Clamp Screw
15	753-05245	Muffler Assembly (includes 16 & 17)	36	712-0161	Nut
16	753-05244	Muffler Gasket	37	841-020761S-1	Shortblock Assem. (incl. 3-11, 18, 39 & 42)
17	710-04809	Muffler Screw	38	750-04434	Spacer
18	794-00098	Spark Plug	39	791-181025	Rocker Cover Screw
19	753-05247	Insulator Gasket	40	753-06949	Heat Shield
20	712-04099	Nut	41	791-181709	Gasket
21	841-020801S	Insulator	42	791-181003	Screw

REPLACEMENT PARTS - MODEL TB304C EC

ELECTRIC START CAPABLE 4-CYCLE TRIMMER

PPN 41AD304C866

Item	Part No.	Description
43	753-09888	Throttle Housing Assem. (incl. 44 - 48)
44	731-08433C-10	Throttle Trigger Lock-Out
45	791-182405	Trigger Switch Assembly
46	753-05007	Throttle Trigger Spring
47	731-04970B-10	Throttle Trigger
48	732-06186	Shoulder Support Clip
49	746P04758	Throttle Cable Assembly
50	841-035632S	Upper Shaft Housing Assembly
51	731-08926	Hanger
52	753-06039	Handle (includes 53)
53	753-06040	Handle Bolt
54	753-1190	Split Boom Coupler (includes 55)
55	791-182057	Anti-Rotation Screw
56	753-09586	Lower Shaft Housing Assembly
57	753-04283	Shield Assembly (includes 58 & 59)
58	753-04282	Shield Mounting Hardware
59	791-180553	Blade Assembly
60	753-08182	Cutting Head Assembly (includes 61)
61	753-08563	Bump Knob

