


REPLACEMENT PARTS - MODEL TB304S

4-CYCLE TRIMMER

PPN 41BD304S766



Item	Part No.	Description	Item	Part No.	Description
1	753-09884	Engine Cover Assembly (includes 2 & 3)	22	753-06948	Carburetor Gasket
2	710-04194	Cover Screw	23	751-22423	Carburetor w/Primer
3	710-04604	Screw	24	791-181003	Screw
4	753-05901	Rocker Cover	25	841-036210S	Air Cleaner Cover Assembly (incl. 26)
5	753-05902	Rocker Cover O-Ring	26	753-05254	Air Filter
6	753-05910	Cylinder O-Ring	27	710-04517	Screw
7	753-10205	Breather Hose	28	753-06797	Fuel Tank Assembly (includes 29)
8	753-05408	Oil Plug (includes 9)	29	753-1229	Fuel Cap
9	791-182290	Oil Plug O-Ring	30	753-05259	Fuel Tank Pads
10	753-06259	Crankcase Cover	31	753-10204	Starter Housing Assembly (incl. 3 & 38)
11	753-05238	Crankcase Cover O-ring	32	753-06281	Clutch Assembly
12	753-06221	Flywheel Assembly	33	753-09887	Clutch Cover (includes 2)
13	753-05264	Lead Wires	34	791-182519	Anti-Rotation Screw
14	753-11255	Module Assembly	35	753-04003	Clamp Screw
15	753-05245	Muffler Assembly (includes 16 & 17)	36	712-0161	Nut
16	753-05244	Muffler Gasket	37	841-021441S	Shortblock Assem. (incl. 3-9, 11, 18, 24 & 39)
17	710-04809	Muffler Screw	38	750-04434	Spacer
18	794-00082	Spark Plug	39	791-181025	Rocker Cover Screw
19	753-05247	Insulator Gasket	40	753-06949	Heat Shield
20	712-04099	Nut	41	791-181709	Gasket
21	841-020801S	Insulator	42	914-04016	Flywheel Key

REPLACEMENT PARTS - MODEL TB304S

4-CYCLE TRIMMER

PPN 41BD304S766

Item	Part No.	Description
43	753-09888	Throttle Housing Assem. (incl. 44 - 48)
44	731-08433C-10	Throttle Trigger Lock-Out
45	791-182405	Trigger Switch Assembly
46	753-05007	Throttle Trigger Spring
47	731-04970B-10	Throttle Trigger
48	732-06186	Shoulder Support Clip
49	746P04758	Throttle Cable Assembly
50	841-035632S	Upper Shaft Housing Assembly
51	731-08926	Hanger
52	753-06039	Handle (includes 53)
53	753-06040	Handle Bolt
54	753-1190	Split Boom Coupler (includes 55)
55	791-182057	Anti-Rotation Screw
56	753-06789	Lower Shaft Housing Assembly
57	753-05267	Lower Flexible Drive Shaft
58	753-08180	Gearbox Assembly (includes 59 - 61)
59	791-182519	Anti-rotation Screw
60	791-182195	Gearbox Mounting Hardware
61	748-05052	Cutting Head Driver
62	841-032093S	Shield Assembly (includes 63 & 64)
63	753-04282	Shield Mounting Hardware
64	753-08355	Blade Assembly
65	841-012478S	Cutting Head Assembly (includes 66)
66	753-08563	Bump Knob

